

SCI INSTRUCTION MANUAL
QUICK REFERENCE GUIDE

TABLE OF CONTENTS

Countertop Care.....	Pages 2
Kitchen & Foyer Floor Care.....	Pages 4
Bathroom Vanity Care.....	Pages 6
Bathroom Floor Care.....	Pages 7
Removing Glass Rings & Dull Spots	Page 9
Stone Showerwalls.....	Pages 10
Stone Fireplaces.....	Pages 12
Tumbled Marble Care.....	Pages 13
Exterior Stone Walls.....	Pages 15
Flamed Granite Care.....	Pages 17
Stain Removal.....	Pages 19
Sealing Stone & Grout Surfaces.....	Pages 21
Slate Tile.....	Pages 23

STONE COUNTERTOP CARE PROGRAM

PRODUCTS NEEDED:

- Stone Spray N Seal
- International Stone Polish
- Marbamist or Clean EnCounters Ready to Use Spray Cleaner
- Counterrific

USE:

USAGE:

Prevents
Staining &
Discoloring
Every 1-2 Years
Enriches the
color of the stone
Monthly
Daily/Weekly

Stone
Disinfectant Spray

Weekly

SEALING: (Every 1-2 years)

Product: Stone Spray N Seal

*Always test first in a small area for desired results before applying to entire surface.
Remove any topical waxes or stains before sealing.

- 1) For maximum protection, surface should be dry for 6-12 hours before sealing.
- 2) Clean countertop surface using Marbamist or Clean EnCounters.
(It is safe to lightly clean the stone before sealing.)
- 3) Cover surrounding areas that are not intended to be sealed.
- 4) Spray sealer onto the stone and saturate the entire surface.
(Outer edges may dry quicker.)
- 5) When surface begins to dry within 3-5 minutes, wet the surface again with the sealer.
(This will allow the sealer to properly penetrate and cure.)
- 6) After ONE HOUR, wipe off excess sealer from the surface with a clean and dry white terry cloth towel.
- 7) If excess dries on the surface, spray more sealer onto the surface and wipe off immediately
with a clean dry terry cloth towel.

-For more porous stones like limestone, slate, and fine-grained granites, repeat steps 3-7 one

hour after the first application or use Stone Spray N Seal **XP**.

-For quality curing results, keep surface dry for 24-48 hours after application. 48 hours is best.

POLISHING & ENRICHING COLOR: (Monthly)

Product: International Stone Polish

- 1) Shake the bottle before using and apply the polish to the stone surface with a clean, dry and white terry cloth towel.
- 2) Let the polish dry to a haze for 2 minutes.
- 3) Wipe off the haze with a clean, dry and white terry cloth towel.

CLEANING: (Daily to Weekly)

Product: Marbamist or Clean EnCounters

- 1) Simply spray Marbamist or Clean EnCounters on to the stone surface.
- 2) Wipe off the cleaner with a clean and dry terry cloth or paper towel.

DISINFECTING: (Weekly)

Product: Counterrific

- 1) Remove any food or debris from the countertop surface.
- 2) Simply spray Counterrific on to the countertop and let it set for five minutes.
- 3) With a moist and clean paper towel, gently wipe it off of the surface. No rinsing required.

KITCHEN & FOYER FLOOR CARE PROGRAM

PRODUCTS NEEDED:

-Stone Spray N Seal

-Marbalex Stone Floor Cleaner

-Marbacream

USE:

Marble Floor Restorer
If Necessary

USAGE:

Prevents
Staining &
Discoloring Every
1-2 Years
Stone Floor Cleaner

Weekly

SEALING: (Every 1-2 years)

Product: Stone Spray N Seal

*Always test first in a small area for desired results before applying to entire surface.

Remove any topical waxes or stains before sealing.

- 1) For maximum protection, surface should be dry for 6-12 hours before sealing.
- 2) For stone flooring, clean with Marbalex. (It is safe to lightly clean the stone before sealing.)
- 3) Cover surrounding areas that are not intended to be sealed.
- 4) Spray sealer onto the stone and saturate the entire surface.
(Outer edges may dry quicker.)
- 5) When surface begins to dry within 3-5 minutes, wet the surface again with the sealer.
(This will allow the sealer to properly penetrate and cure.)
- 6) After ONE HOUR, wipe off excess sealer from the surface with a clean and dry white terry cloth towel.
- 7) If excess dries on the surface, spray more sealer onto the surface and wipe off immediately
with a clean dry terry cloth towel.

-Floor surfaces may be walked on 4 hours after the application.

-For more porous stones like limestone, slate, and fine-grained granites, repeat steps 3-7 one

hour after the first application or use Stone Spray N Seal **XP**.

-For quality curing results, keep surface dry for 24-48 hours after application. 48 hours is best.

CLEANING: (Daily to Weekly)

Product: Marbalex

- 1) Dry/Dust mop the floor at least twice per week.
- 2) Pour 2 ounces of Marbalex into a clean bucket of water.

(Be sure that the bucket has been thoroughly cleaned out if it has been used before with another cleaner.)

- 3) With a clean rayon of sponge mop, gently mop the Marbalex on to the floor surface without making large puddles.
- 4) Let the surface dry. There is no rinsing required.

POLISHING MARBLE FLOORS: (If Necessary)

Product: Marbacream

Complete small areas no more than six square feet at a time.

- 1) Remove any abrasive debris from the surface.
- 2) Apply clean water to the surface first.
- 3) Shake the bottle until the product thickens.
- 4) Apply the Marbacream to the surface and beginning buffing it in with a red or hogs-hair buffing pad. (This can be done by hand or with an orbital floor buffing machine.)
- 5) Remove the Marbacream once the polish has been achieved by rinsing thoroughly with Marbalex.
- 6) Wipe off the haze with a clean, dry and white terry cloth towel.

BATHROOM STONE VANITY CARE PROGRAM

PRODUCTS NEEDED:

-Stone Spray N Seal

-International Stone Polish

-Counterterific

USE:

USAGE:

Prevents
Staining &
Discoloring
Every 1-2 Year
Enriches the
color of the stone
Monthly

Stone & Tile Disinfectant Spray
Daily/Weekly

SEALING: (Every 1-2 years)

Product: Stone Spray N Seal

*Always test first in a small area for desired results before applying to entire surface.
Remove any topical waxes or stains before sealing.

- 1) For maximum protection, surface should be dry for 6-12 hours before sealing.
- 2) Clean countertop surface using Counterterific.
(It is safe to lightly clean the stone before sealing.)
- 3) Cover surrounding areas that are not intended to be sealed.
- 4) Spray sealer onto the stone and saturate the entire surface.
(Outer edges may dry quicker.)
- 5) When surface begins to dry within 3-5 minutes, wet the surface again with the sealer.
(This will allow the sealer to properly penetrate and cure.)
- 6) After ONE HOUR, wipe off excess sealer from the surface with a clean and dry white terry cloth towel.
- 7) If excess dries on the surface, spray more sealer onto the surface and wipe off immediately
with a clean dry terry cloth towel.

-For more porous stones like limestone, slate, and fine-grained granites, repeat steps 3-7 one

hour after the first application or use Stone Spray N Seal **XP**.

-For quality curing results, keep surface dry for 24-48 hours after application. 48 hours is best.

POLISHING & ENRICHING COLOR: (Monthly)

Product: International Stone Polish

- 1) Shake the bottle before using and apply the polish to the stone surface with a clean, dry and white terry cloth towel.

- 2) Let the polish dry to a haze for 2 minutes.
- 3) Wipe off the haze with a clean, dry and white terry cloth towel.

DISINFECTING: (Daily to Weekly)

Product: Counterrific

- 1) Simply spray Counterrific on to the stone surface.
- 2) Wipe off after five minutes with a clean and dry terry cloth or paper towel.

BATHROOM STONE FLOOR CARE PROGRAM

PRODUCTS NEEDED:

-Stone Spray N Seal

-Marbadan Plus Disinfectant

-Marbacream

Necessary

Marble Floor Restorer

USE:

USAGE:

Prevents
Staining &
Discoloring
Every 1-2 Years
Disinfectant
Cleaner

Weekly

If

SEALING: (Every 1-2 years)

Product: Stone Spray N Seal

*Always test first in a small area for desired results before applying to entire surface.

Remove any topical waxes or stains before sealing.

- 1) For maximum protection, surface should be dry for 6-12 hours before sealing.
- 2) For stone flooring, clean with Marbadan Plus.
(It is safe to lightly clean the stone before sealing.)
- 3) Cover surrounding areas that are not intended to be sealed.
- 4) Spray sealer onto the stone and saturate the entire surface.
(Outer edges may dry quicker.)
- 5) When surface begins to dry, within 3-5 minutes, wet the surface again with the sealer.
(This will allow the sealer to properly penetrate and cure.)
- 6) After ONE HOUR, wipe off excess sealer from the surface with a clean and dry white terry cloth towel.
- 7) If excess dries on the surface, spray more sealer onto the surface and wipe off immediately
with a clean dry terry cloth towel.

-Floor surfaces may be walked on 4 hours after the application.

-For more porous stones like limestone, slate, and fine-grained granites, repeat steps 3-7 one

hour after the first application or use Stone Spray N Seal **XP**.

-For quality curing results, keep surface dry for 24-48 hours after application. 48 hours is best.

DISINFECTING/CLEANING: (Daily to Weekly)

Product: Marbadan Plus

- 1) Dry/Dust mop the floor at least twice per week.
- 2) Pour 1 ounce of Marbadan Plus per gallon of water into a clean bucket of water.
(Be sure that the bucket has been thoroughly cleaned out if it has been used before with another cleaner.)
- 3) With a clean rayon of sponge mop, gently mop the Marbadan Plus on to the floor surface without making large puddles.
- 4) Let the surface dry. There is no rinsing required.

POLISHING MARBLE FLOORS: (If Necessary)

Product: Marbacream

Complete small areas no more than six square feet at a time.

- 1) Remove any abrasive debris from the surface.
- 2) Apply clean water to the surface first.
- 3) Shake the bottle until the product thickens.
- 4) Apply the Marbacream to the surface and beginning buffing it in with a red or hogs-hair buffing pad. (This can be done by hand or with an orbital floor buffing machine.)
- 5) Remove the Marbacream once the polish has been achieved by rinsing thoroughly with Marbalex.
- 6) Wipe off the haze with a clean, dry and white terry cloth towel.

REMOVING GLASS-RINGS & DULL SPOTS

PRODUCTS NEEDED:

-Marbacream

-International Stone Polish

-Marbamist or Clean EnCounters Ready to Use Spray Cleaner

USE:

USAGE:

Glass Ring
Remover

As Needed
Enriches the
color of the stone

Monthly
Daily/Weekly

REMOVING GLASS RINGS & DULL SPOTS: (As Needed)

Product: Marbacream

- 1) Clean the surface with Marbamist or Clean EnCounters.
- 2) Shake the Marbacream bottle until the product thickens.
- 3) Add a few drops of water to the damaged area.
- 4) Apply a dab of Marbacream to the damaged area.
- 5) With a clean and damp red buffing pad or white terry cloth towel, begin buffing in a circular motion for 30 seconds. (Be sure to apply pressure when polishing.)
 - **Repeat steps 2-5 if the polish is not achieved.
 - ***If the surface is rough to the touch, Honex must be used before the Marbacream.
- 6) Rinse with either Marbamist or Clean EnCounters and wipe it dry.
- 7) Apply one coat of International Stone Polish to complete the process. (Do not apply the International Stone Polish to floor surfaces.)

POLISHING & ENRICHING COLOR: (Monthly)

Product: International Stone Polish

- 1) Shake the bottle before using and apply the polish to the marble surface with a clean, dry and white terry cloth towel.
- 2) Let the polish dry to a haze for 2 minutes.
- 3) Wipe off the haze with a clean, dry and white terry cloth towel.

CLEANING: (Daily to Weekly)

Product: Marbamist or Clean EnCounters

- 1) Simply spray Marbamist or Clean EnCounters on to the stone surface.
- 2) Wipe off the cleaner with a clean and dry terry cloth or paper towel.

**For Bathrooms, use Marbadan Plus Disinfectant instead of Marbamist or Clean EnCounters.

STONE SHOWERWALL CARE PROGRAM

PRODUCTS NEEDED:

USE:

-Stone Spray N Seal

USAGE:

Prevents
Staining &
Discoloring
Every 1-2
Years

-International Stone Polish
-Counterterrific

Provides Additional Water Repellency Monthly
Ready to Use Disinfectant Spray

Daily/Weekly

-Marbacream Marble Restorer

Removes Dull Spots, Water Spots, & As Needed
Water Streaks.

SEALING: (Every 1-2 years)

Product: Stone Spray N Seal

*Always test first in a small area for desired results before applying to entire surface.
Remove any topical waxes or stains before sealing.

- 1) For maximum protection, surface should be dry for 6-12 hours before sealing.
- 2) Clean wall surfaces using Counterterrific, Marbamist or Clean EnCounters.
(It is safe to lightly clean the stone before sealing.)
- 3) Cover surrounding areas that are not intended to be sealed.
- 4) Spray sealer onto the stone and saturate the entire surface.
(Outer edges may dry quicker.)
- 5) When surface begins to dry within 3-5 minutes, wet the surface again with the sealer.
(This will allow the sealer to properly penetrate and cure.)
- 6) After ONE HOUR, wipe off excess sealer from the surface with a clean and dry white terry cloth towel.
- 7) If excess dries on the surface, spray more sealer onto the surface and wipe off immediately
with a clean dry terry cloth towel.

-For more porous stones like limestone, slate, and fine-grained granites, repeat steps 3-7 one

hour after the first application or use Stone Spray N Seal **XP**.

-For quality curing results, keep surface dry for 24-48 hours after application. 48 hours is best.

POLISHING & ADDITIONAL WATER REPELLENCY: (Monthly)

Product: International Stone Polish

- 1) Shake the bottle before using and apply the polish to the stone surface with a clean, dry and white terry cloth towel.
- 2) Let the polish dry to a haze for 2 minutes.
- 3) Wipe off the haze with a clean, dry and white terry cloth towel.

CLEANING & DISINFECTING: (Daily to Weekly)

Product: Counterrific

- 1) Simply spray Counterrific on to the stone surface.
- 2) Wipe off the Counterrific with a clean and dry terry cloth or paper towel.

REMOVING DULL SPOTS, WATER SPOTS, & WATER STREAKS:

Product: Marbacream

- 1) Shake the bottle until the Marbacream thickens.
- 2) Apply water to the marble surface and then apply the Marbacream to a piece of a red buffing pad.
- 3) Begin buffing the marble surface in a circular motion while applying pressure.
- 4) Apply more water as needed and stop buffing when the marks are removed.
- 5) Rinse with Marbamist.
- 6) Apply one coat of International Stone Polish.

STONE FIREPLACE CARE PROGRAM

PRODUCTS NEEDED:

- Stone Spray N Seal
- International Stone Polish
- Marbamist or Clean EnCounters Ready to Use Spray Cleaner

USE:

USAGE:

Prevents
Staining &
Discoloring
Every 1-2 Years
Enriches the
color of the stone
Monthly
Daily/Weekly

SEALING: (Every 1-2 years)

Product: Stone Spray N Seal

*Always test first in a small area for desired results before applying to entire surface.
Remove any topical waxes or stains before sealing.

- 1) For maximum protection, surface should be dry for 6-12 hours before sealing.
- 2) Clean fireplace surround using Marbamist or Clean EnCounters. For extremely soiled surfaces, use Stone Quest. (It is safe to lightly clean the stone before sealing.)
- 3) Cover surrounding areas that are not intended to be sealed.
- 4) Spray sealer onto the stone and saturate the entire surface.
(Outer edges may dry quicker.)
- 5) When surface begins to dry within 3-5 minutes, wet the surface again with the sealer.
(This will allow the sealer to properly penetrate and cure.)
- 6) After ONE HOUR, wipe off excess sealer from the surface with a clean and dry white terry cloth towel.
- 7) If excess dries on the surface, spray more sealer onto the surface and wipe off immediately
with a clean dry terry cloth towel.

-For more porous stones like limestone, slate, and fine-grained granites, repeat steps 3-7 one

hour after the first application or use Stone Spray N Seal **XP**.

-For quality curing results, keep surface dry for 24-48 hours after application. 48 hours is best.

POLISHING & ENRICHING COLOR: (Monthly)

Product: International Stone Polish

- 1) Shake the bottle before using and apply the polish to the stone surface with a clean, dry and white terry cloth towel.

- 2) Let the polish dry to a haze for 2 minutes.
- 3) Wipe off the haze with a clean, dry and white terry cloth towel.

CLEANING: (Daily to Weekly)

Product: Marbamist or Clean EnCounters

- 1) Simply spray Marbamist or Clean EnCounters on to the stone surface.
- 2) Wipe off the cleaner with a clean and dry terry cloth or paper towel.

TUMBLER MARBLE CARE PROGRAM
Cleaning, Sealing, Color Enhancing

PRODUCTS NEEDED: USE:

-Stone Spray N Seal **XP**

-Stone Color Enhancer
-Marbamist or Clean EnCounters

-Marbalex

USAGE:

Prevents
Staining &
Discoloring Every
1-2 Years
Every 2 Years
Cleaning Stone
Countertops
Daily/Weekly

Enhancing/Sealing Tumbled Stone

Cleaning Stone Floors
Weekly

SEALING: (Every 1-2 years)

Product: Stone Spray N Seal *(Do not use if using the Stone Color Enhancer)*

*Always test first in a small area for desired results before applying to entire surface.

Remove any topical waxes or stains before sealing.

- 1) For maximum protection, surface should be dry for 6-12 hours before sealing.
- 2) Clean countertop surfaces using Marbamist or Clean EnCounters. For stone flooring, clean with Marbalex. (It is safe to lightly clean the stone before sealing.)
- 3) Cover surrounding areas that are not intended to be sealed.
- 4) Spray sealer onto the stone and saturate the entire surface. (Outer edges may dry quicker.)
- 5) When surface begins to dry, within 3-5 minutes, wet the surface again with the sealer. (This will allow the sealer to properly penetrate and cure.)
- 6) After ONE HOUR, wipe off excess sealer from the surface with a clean and dry white terry cloth towel.
- 7) If excess dries on the surface, spray more sealer onto the surface and wipe off immediately with a clean dry terry cloth towel.

-For more porous stones like limestone, slate, and fine-grained granites, repeat steps 3-7 one

hour after the first application or use Stone Spray N Seal **XP**.

-Floor surfaces may be walked on 4 hours after application

-For quality curing results, keep surface dry for 24-48 hours after application. 48 hours is best.

COLOR ENHANCING TUMBLER MARBLE SURFACES:

Product: Stone Color Enhancer

The Stone Color Enhancer will also seal. Do not apply Stone Spray N Seal with it.

- 1) Be sure that the surface is completely clean and dry before applying it to the surface.
- 2) Apply Stone Color Enhancer to a clean and dry white terry cloth towel or pour it into a solvent-resistant spray bottle.
- 3) Apply the Stone Color Enhancer evenly to the surface wetting small areas at a time without making puddles.
- 4) Apply a second application five minutes after the first and let it dry.
- 5) Do not let the surface get wet for 24 hours after the sealer application.
- 6) Maintain the surfaces with the appropriate SCI Cleaner.

(SCI recommends not using rollers when applying the Sealer or Stone Color Enhancer)

CLEANING FLOORS:

Product: Marbalex Daily Stone Floor Cleaner

- 1) Mix 2 ounces of Marbalex per one gallon of clean water.
- 2) Using a clean rayon mop or sponge mop, apply the solution to the floor surface.
- 3) Let the solution dry. (There is no rinsing required.)

*For disinfecting, use Marbadan Plus.

DAILY CLEANING COUNTERTOPS:

Product: Marbamist Stone Countertop Spray Cleaner or Clean EnCounters

- 1) Simply spray the Marbamist to the surface.
 - 2) Wipe off with a clean and dry towel.
- *For areas with heavy grease, let the Marbamist set for 30 seconds and then wipe off. A second application may be needed.

*For disinfecting, use Counterrific.

EXTERIOR STONE WALLS

PRODUCTS NEEDED:

-Stone Spray N Seal

-International Stone Polish
-Marbamist or Clean EnCounters
-Marbacream Marble Restorer

Provides Additional Water Repellency
Ready to Use Spray Cleaner
Removes Dull Spots, Water Spots, &
Water Streaks.

USE:

USAGE:

Prevents
Staining &
Discoloring
Every 1-2 Years
Monthly
Daily/Weekly
As Needed

SEALING: (Every 1-2 years)

Product: Stone Spray N Seal

*Always test first in a small area for desired results before applying to entire surface.
Remove any topical waxes or stains before sealing.

- 1) For maximum protection, surface should be dry for 6-12 hours before sealing.
- 2) Clean wall surface using Marbamist or Clean EnCounters.
(It is safe to lightly clean the stone before sealing.)
- 3) Cover surrounding areas that are not intended to be sealed.
- 4) Spray sealer onto the stone and saturate the entire surface.
(Outer edges may dry quicker.)
- 5) When surface begins to dry, within 3-5 minutes, wet the surface again with the sealer.
(This will allow the sealer to properly penetrate and cure.)
- 6) After ONE HOUR, wipe off excess sealer from the surface with a clean and dry white terry cloth towel.
- 7) If excess dries on the surface, spray more sealer onto the surface and wipe off immediately
with a clean dry terry cloth towel.

-For more porous stones like limestone, slate, and fine-grained granites, repeat steps 3-7 one

hour after the first application or use Stone Spray N Seal **XP**.

-For quality curing results, keep surface dry for 24-48 hours after application. 48 hours is best.

POLISHING & ADDITIONAL WATER REPELLENCY: (Monthly)

Product: International Stone Polish

- 1) Shake the bottle before using and apply the polish to the stone surface with a clean, dry and white terry cloth towel.

- 2) Let the polish dry to a haze for 2 minutes.
- 3) Wipe off the haze with a clean, dry and white terry cloth towel.

CLEANING: (Daily to Weekly)

Product: Stone Quest

- 1) Simply mix 2 ounces of Stone Quest with water and spray on to the surface.
- 2) Wipe off the Stone Quest with a clean and dry terry cloth or paper towel.

REMOVING DULL SPOTS, WATER SPOTS, & WATER STREAKS:

Marble & Limestone:

Product: Marbacream

- 1) Shake the bottle until the Marbacream thickens.
- 2) Apply water to the marble surface and then apply the Marbacream to a piece of a red buffing pad.
- 3) Begin buffing the marble surface in a circular motion while applying pressure.
- 4) Apply more water as needed and stop buffing when the marks are removed.
- 5) Rinse with Stone Quest.
- 6) Once the surface has been dry for 24 hours, seal the stone surface with Stone Spray N Seal.

Granite:

Product: SCI-GD Dark Granite Polishing Powder

or

SCI-GL Light Granite Polishing Powder

- 1) Mix the granite polishing powder with water and paste it on the wall.
- 2) Using a hand-held buffing machine with either a felt pad or hogs hair pad, begin buffing in a circular motion.
(Pressure must be applied and continue to spray water on the surface as it begins drying.)
- 3) Continue buffing until water streaks are gone.
- 4) Rinse with Stone Quest
- 5) Once the surface has been dry for 24 hours, seal the stone surface with Stone Spray N Seal.

FLAMED GRANITE CARE PROGRAM
Cleaning, Sealing, Color Enhancing

PRODUCTS NEEDED: USE:

-Stone Spray N Seal XP

-Stone Color Enhancer
-Stone Quest

USAGE:

	Prevents
	Staining &
	Discoloring
	Every
	1-2 Years
Enhancing/Sealing Tumbled Stone	Every 2 Years
Cleaning Stone Floors	
Daily	

SEALING: (Every 1-2 years)

Product: Stone Spray N Seal XP

*Always test first in a small area for desired results before applying to entire surface.
Remove any topical waxes or stains before sealing.

- 1) For maximum protection, surface should be dry for 6-12 hours before sealing.
- 2) Clean countertop surface using Marbamist or Clean EnCounters. For stone flooring, clean with Marbalex. For heavily soiled surfaces, use Stone Quest. (It is safe to lightly clean the stone before sealing.)
- 3) Cover surrounding areas that are not intended to be sealed.
- 4) Spray sealer onto the stone and saturate the entire surface. (Outer edges may dry quicker.)
- 5) When surface begins to dry within 3-5 minutes, wet the surface again with the sealer. (This will allow the sealer to properly penetrate and cure.)
- 6) After ONE HOUR, wipe off excess sealer from the surface with a clean and dry white terry cloth towel.
- 7) If excess dries on the surface, spray more sealer onto the surface and wipe off immediately with a clean dry terry cloth towel.

-For more porous stones, repeat steps 3-7 one hour after the first application.
-Floor surfaces may be walked on 4 hours after application
-For quality curing results, keep surface dry for 24-48 hours after application. 48 hours is best.

COLOR ENHANCING FLAMED GRANITE SURFACES:

Product: Stone Color Enhancer & Sealer

The Stone Color Enhancer will also seal. Do not apply Stone Spray N Seal XP with it.

- 1) Be sure that the surface is completely clean and dry before applying it to the surface.
- 2) Pour the Stone Color Enhancer into a labeled solvent-resistant spray bottle.
- 3) Apply the Stone Color Enhancer evenly to the surface wetting small areas at a time without making puddles.
- 4) Apply a second application five minutes after the first and let it dry.
- 5) Do not let the surface get wet for 24 hours after the sealer application.
- 6) Maintain the surfaces with the appropriate SCI Cleaner.

(SCI recommends not using rollers when applying the Sealer or Stone Color Enhancer)

SCRUBBING FLAMED GRANITE: (Interior Daily, Exterior Monthly)

Product: Stone Quest

- 1) Remove all abrasive debris from the floor surface.
- 2) Mix 2-4 ounces of Stone Quest per gallon of warm water.
- 3) With a clean bucket and rayon mop, apply the Stone Quest to the surface.
- 4) With a 175 rpm floor machine and a Stoneglide Beta Brush, begin scrubbing the floor surface. Make 10 passes.
- 5) Pick up the excess with a wet/dry vacuum.
- 6) Rinse with Stone Quest mixed at 1 ounce per gallon of water.

AUTOMATIC-SCRUBBING FLAMED GRANITE FLOORS: (Daily)

Product: Stone Quest

- 1) Remove all abrasive debris from the floor surface with a dry/dust mop.
- 2) Mix 1 ounce of Stone Quest per gallon of water in to the scrubber tank.
- 3) Using the Stoneglide Beta Brushes, begin scrubbing the floor area.
(Double scrubbing should be done twice per week)

PRESSURE-WASHING FLAMED GRANITE: (As Needed)

Product: Stone Quest

- 1) Mix 2 ounces of Stone Quest per one gallon of clean water.
- 2) Begin spraying the solution to the surface.

3) Rinse with water.

STONE & GROUT STAIN REMOVAL

PRODUCTS NEEDED:

-OPP Oil Poultice Powder

-RPP Rust Poultice Powder

-FPP Food Poultice Powder

-IPP Ink Poultice Powder

-MPP Mold/Mildew Poultice Powder
-Marbamist, Marbalex

-Stone Spray N Seal

Removes Mold/Mildew Stains As Needed

Sealer

USE:

USAGE:

Removes

Oil Stains

As Needed

Removes

Rust Stains As Needed

Removes

Food Stains As Needed

Removes

Ink Stain

As Needed

Spray
Cleaner for Stone

Daily/Weekly
Every 1-2 Years

STAIN REMOVAL: (As Needed)

Product: Select the correct stain remover.

- 1) Identify the type of stain and select the correct SCI Poultice Powder.
- 2) Wet the stained area with distilled water.
- 3) Blend the powder with water to a thick paste consistency.
- 4) Place the poultice to the stained area only.
- 5) Cover the poultice with plastic wrap to keep it air tight.
*Place five tiny holes in the wrap with a needle.
- 6) The poultice must be completely dry and hard before removing the wrap. (24-48 hours)
THE DRYING OF THE POULTICE IS WHAT REMOVES THE STAIN
- 7) When dry, take the wrap off and remove the dry poultice with a wooden spatula.
- 8) If the stain reappears, repeat the process again.
* Etching may occur from the RPP Rust Poultice Powder. The etch can be removed with Marbacream.
- 9) After 24 hours of being dry, seal with Stoneguard.
- 10) Clean daily with Marbamist or Clean EnCounters.

CLEANING: (Daily to Weekly)

Product: Marbamist or Clean EnCounters

- 1) Simply spray Marbamist or Clean EnCounters on to the stone surface.
- 2) Wipe off the cleaner with a clean and dry terry cloth or paper towel.

SEALING: (Every 1-2 years)

Product: Stone Spray N Seal

*Always test first in a small area for desired results before applying to entire surface.
Remove any topical waxes or stains before sealing.

- 1) For maximum protection, surface should be dry for 6-12 hours before sealing.
- 2) Clean countertop surface using Marbamist or Clean EnCounters. For stone flooring, clean with Marbalex. Use Stone Quest for heavily soiled surfaces.
(It is safe to lightly clean the stone before sealing.)
- 3) Cover surrounding areas that are not intended to be sealed.
- 4) Spray sealer onto the stone and saturate the entire surface.
(Outer edges may dry quicker.)
- 5) When surface begins to dry within 3-5 minutes, wet the surface again with the sealer.
(This will allow the sealer to properly penetrate and cure.)
- 6) After ONE HOUR, wipe off excess sealer from the surface with a clean and dry white terry cloth towel.
- 7) If excess dries on the surface, spray more sealer onto the surface and wipe off immediately with a clean dry terry cloth towel.

-For more porous stones like limestone, slate, and fine-grained granites, repeat steps 3-7 one

hour after the first application or use Stone Spray N Seal **XP**.

-Floor surfaces may be walked on 4 hours after application

-For quality curing results, keep surface dry for 24-48 hours after application. 48 hours is best.

SEALING STONE & GROUT SURFACES

SEALERS NEEDED:

-Stone Spray N Seal

or

-Stone Spray N Seal **XP**

USE:

USAGE:

Seals

Stone & Grout

Every 1-2 Years

Seals Extra Porous Stones & Grout

Every 1-2 Years

KITCHEN COUNTERTOPS & BATHROOM VANITIES:

*Always test first in a small area for desired results before applying to entire surface.
Remove any topical waxes or stains before sealing.

- 1) For maximum protection, surface should be dry for 6-12 hours before sealing.
- 2) Clean countertop surface using Marbamist or Clean EnCounters. For stone flooring, clean with Marbalex. (It is safe to lightly clean the stone before sealing.)
- 3) Cover surrounding areas that are not intended to be sealed.
- 4) Spray sealer onto the stone and saturate the entire surface. (Outer edges may dry quicker.)
- 5) When surface begins to dry within 3-5 minutes, wet the surface again with the sealer. (This will allow the sealer to properly penetrate and cure.)
- 6) After ONE HOUR, wipe off excess sealer from the surface with a clean and dry white terry cloth towel.
- 7) If excess dries on the surface, spray more sealer onto the surface and wipe off immediately with a clean dry terry cloth towel.

-For more porous stones like limestone, slate, and fine-grained granites, repeat steps 3-7 one

hour after the first application or use Stone Spray N Seal **XP**.

-Floor surfaces may be walked on 4 hours after application

-For quality curing results, keep surface dry for 24-48 hours after application. 48 hours is best.

SEALING STONE WALLS:

-Follow Procedures 1-7 using Marbamist or Clean EnCounters.

SEALING FIREPLACE SURROUNDS:

- Follow Procedures 1-7 using Marbamist or Clean EnCounters before sealing.
- Use Stone Quest for heavily soiled surfaces before sealing.

SEALING FLAMED GRANITE & TUMBLED MARBLE SURFACES:

- Follow Procedures 1-7 using Stone Quest before sealing.
- Use Stone Spray N Seal **XP** for sealing .

SEALING TUMBLED MARBLE SURFACES:

- Follow Procedures 1-7 using Marbalex for floors, Marbamist or Clean EnCounters for Countertops.
- Use Stone Spray N Seal **XP** for sealing .

SLATE CARE PROGRAM
Cleaning, Sealing, Color Enhancing

PRODUCTS NEEDED: USE:

-Stone Spray N Seal **XP**

-Stone Color Enhancer
-Marbamist or Clean EnCounters

-Marbalex

USAGE:

Enhancing/Sealing Tumbled Stone

Cleaning Stone Floors
Weekly

Prevents
Staining &
Discoloring Every
1-2 Years
Every 2 Years
Cleaning Stone
Countertops
Daily/Weekly

SEALING: (Every 1-2 years)

Product: Stone Spray N Seal *(Do not use if using the Stone Color Enhancer)*

*Always test first in a small area for desired results before applying to entire surface.

Remove any topical waxes or stains before sealing.

- 1) For maximum protection, surface should be dry for 6-12 hours before sealing.
- 2) Clean countertop surfaces using Marbamist or Clean EnCounters. For stone flooring, clean with Marbalex. (It is safe to lightly clean the stone before sealing.)
- 3) Cover surrounding areas that are not intended to be sealed.
- 4) Spray sealer onto the stone and saturate the entire surface. (Outer edges may dry quicker.)
- 5) When surface begins to dry within 3-5 minutes, wet the surface again with the sealer. (This will allow the sealer to properly penetrate and cure.)
- 6) After ONE HOUR, wipe off excess sealer from the surface with a clean and dry white terry cloth towel.
- 7) If excess dries on the surface, spray more sealer onto the surface and wipe off immediately with a clean dry terry cloth towel.

-For more porous stones like limestone, slate, and fine-grained granites, repeat steps 3-7 one

hour after the first application or use Stone Spray N Seal **XP**.

-Floor surfaces may be walked on 4 hours after application

-For quality curing results, keep surface dry for 24-48 hours after application. 48 hours is best.

COLOR ENHANCING TUMBLED MARBLE SURFACES:

Product: Stone Color Enhancer

The Stone Color Enhancer will also seal. Do not apply Stone Spray N Seal with it.

- 1) Be sure that the surface is completely clean and dry before applying it to the surface.
- 2) Apply Stone Color Enhancer to a clean and dry white terry cloth towel or pour it into a solvent-resistant spray bottle.
- 3) Apply the Stone Color Enhancer evenly to the surface wetting small areas at a time without making puddles.
- 4) Apply a second application five minutes after the first and let it dry.
- 5) Do not let the surface get wet for 24 hours after the sealer application.
- 6) Maintain the surfaces with the appropriate SCI Cleaner.

(SCI recommends not using rollers when applying the Sealer or Stone Color Enhancer)

CLEANING FLOORS:

Product: Marbalex Daily Stone Floor Cleaner

- 1) Mix 2 ounces of Marbalex per one gallon of clean water.
- 2) Using a clean rayon mop or sponge mop, apply the solution to the floor surface.
- 3) Let the solution dry. (There is no rinsing required.)

*For disinfecting, use Marbadan Plus.

DAILY CLEANING COUNTERTOPS:

Product: Marbamist Stone Countertop Spray Cleaner or Clean EnCounters

- 1) Simply spray the Marbamist to the surface.
 - 2) Wipe off with a clean and dry towel.
- *For areas with heavy grease, let the Marbamist set for 30 seconds and then wipe off. A second application may be needed.

*For disinfecting, use Counterrific.